CRH AUSTRALIA
SOLUTIONS FOR TRADE ®

PVC Strip Door Curtains – How to Measure



Daylight Opening (DLO)

The clear, unobstructed opening that the PVC strip curtain needs to cover.

1 Opening Width
Measure the full clear opening from left to right, between the inside edges of the door frame.

2 Opening Height
Measure vertically from the proposed curtain mounting position down to the finished floor level.

Please provide both measurements in millimetres (mm).

PVC Strip Door Curtains – How to Measure

To ensure your PVC strip curtain is made to the correct size, please provide the **Daylight Opening** measurements.

The Daylight Opening is the **clear, unobstructed opening** that the PVC strip curtain needs to cover.

1 **Opening Width:** Measure the full clear opening from left to right, between the inside edges of the door frame.

2 **Opening Height:** Measure vertically from the top of the opening down to the finished floor level.

Please provide both measurements in millimetres (mm).

Important: These measurements will help us determine the correct curtain width, strip length and required floor clearance.